

Installation Instructions for Fernco Large Diameter Couplings

- Lay the proper pipe bedding.
- When cutting pipe sections take care to cut as straight as possible.
- Clean the pipe sections, they should be free from any dirt or debris.
- Slide the Fernco reducer bushing onto the smaller pipe section. Slide it far enough to allow room for the entire coupling. (the lip of the bushing first)
- Slide the coupling onto the reducer bushing with the end of the pipe exposed.
- Place the other pipe section in position.
- Slide the coupling and bushing assembly down the pipe so there is an even amount of the coupling on each of the two pipe sections
- Tighten the stainless steel clamps to 60"lbs. torque, at each clamp housing.
- Backfill