

LDCX Installation with Reducer and LDCMA

1. First slide the LDCX coupling onto the larger pipe.
2. Install the LDCMA approx 6" from the end of the smaller pipe. Use the Bands provided with the LDCMA on the center band groove. Tightening Bands down to 60 inch pounds of torque.



SECTION A-A
SCALE 1 : 2.5

3. Next place the Reducer Bushing over the LDCMA with the lip facing away from the larger pipe.



SECTION A-A
SCALE 1 : 2.5

4. Slide the LDCX coupling from the larger pipe over until it fits under the lip of the Reducer Bushing.





SECTION A-A
SCALE 1 : 2.5

5. Place Clamps provided with LDCX coupling in Band Grooves and tighten all Bands down to 60 inch pounds of Torque.

NOTES: Our product is not intended to support the weight of the connection. The pipes must be Bedded and Backfilled properly when using our product.